


# Maytag LDG31CA 09 - LINT SCREEN-LOWER FRONT



Maytag Residential Maytag LDG31CA Dryer Parts Parts Diagram 09 - LINT SCREEN-LOWER FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y055980</a>			Hi-Temp Adhesive, 2 Oz Tube
002	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
003	NLA		Not Available	LEVELING LEG
004	Y330071		Not Available	IMPELLER FOR BLOWER
005	<a href="#">Y330078</a>			Cool-Down Bypass Switch
006	<a href="#">Y330086</a>			Lint Screen With Frame
007	331005	<a href="#">701719</a>		Nut, Hex
008	NLA		Not Available	WING NUT, LINT HOOD
009	NLA		Not Available	WASHER, LINT HOOD
010	331031		Not Available	SET SCREW FOR IMPELLER
011	331032	<a href="#">61002031</a>		Screw, Handle
012	<a href="#">331036</a>			Washer-Front Panel Screws
013	<a href="#">331053</a>			Damper
014	NLA		Not Available	HINGE PIN, DAMPER
015	NLA		Not Available	SHIELD, DAMPER SWITCH
016	NLA		Not Available	TWIN FASTENER W/SCREWS

