


Maytag LDG31CT 05 - DOOR SWTCH, TEMP CNTRL, TERMINAL BLOCK

MODEL DG31CA-CM-CT

DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK



Maytag Residential Maytag LDG31CT Dryer Parts Parts Diagram 05 - DOOR SWTCH, TEMP CNTRL, TERMINAL BLOCK

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	212220	213501		Screw, No.6-20 X 1-1/8 Inch
005	212951			Screw, No.6-32 X 1/4 Inch
006	NLA		Not Available	CLIP - ACTUATOR TO CABINET
007	Y330083		Not Available	CONTROL, TEMPERATURE
008	Y330087			Drum Assembly Complete
009	Y330092			Terminal Block
010	NLA		Not Available	FRONT PANEL-WHITE
011	NLA		Not Available	FRONT PANEL-ALMOND
012	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
013	Y330100		Not Available	COIN BOX ASSEMBLY
014	Y330147			Part Not Used

015	NLA		Not Available	VAULT ASSEMBLY
016	NLA		Not Available	SCREW - BRACKET TO VAULT
017	331012	400022-1		Screw
018	331014	8281196		Screw
019	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
020	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
021	331058			Grommet-Temp. Control Tubin
022	331061			Knob For Temperature Contro
023	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
024	NLA		Not Available	DRUM ROD
025	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
026	NLA		Not Available	SCREW-TEMP CONTROL LEVER
027	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
028	331151			Lever-Temperature Control
029	NLA		Not Available	NUT FOR CONDUIT
030	331230			Clip
031	NLA		Not Available	TWIN FASTENER WITH SCREWS

