


# Maytag LDG31CT 08 - LINT SCREEN-LOWER FRONT



Maytag Residential Maytag LDG31CT Dryer Parts Parts Diagram 08 - LINT SCREEN-LOWER FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y055980</a>			Hi-Temp Adhesive, 2 Oz Tube
002	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
003	NLA		Not Available	LEVELING LEG
004	Y330071		Not Available	IMPELLER FOR BLOWER
005	<a href="#">Y330078</a>			Cool-Down Bypass Switch
006	<a href="#">Y330086</a>			Lint Screen With Frame
007	331005	<a href="#">701719</a>		Nut, Hex
008	NLA		Not Available	WING NUT - LINT HOOD TO CAB
009	NLA		Not Available	WASHER-LINT HOOD TO CABINET
010	331031		Not Available	SET SCREW FOR IMPELLER
011	331032	<a href="#">61002031</a>		Screw, Handle
012	<a href="#">331036</a>			Washer-Front Panel Screws
013	<a href="#">331053</a>			Damper
014	NLA		Not Available	HINGE PIN FOR DAMPER
015	NLA		Not Available	SHIELD FOR DAMPER

015

NLA

Not Available

SWITCH

016

NLA

Not Available

TWIN FASTENER WITH  
SCREWS

017

911852

[486009](#)

Lockwasher

