


Maytag LDG31CT 13 - CT CONTROL CENTER COMPONENTS



Maytag [Residential Maytag LDG31CT Dryer Parts](#) Parts Diagram 13 - CT CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TICKET RECEIVER ASSEMBLY
002	212220	213501		Screw, No.6-20 X 1-1/8 Inch
003	212951			Screw, No.6-32 X 1/4 Inch
004	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
005	Y330064			Pilot Light
006	NLA		Not Available	CLIP - ACTUATOR TO CABINET
007	Y330083		Not Available	CONTROL, TEMPERATURE
008	NLA		Not Available	FRONT PANEL-WHITE
009	NLA		Not Available	FRONT PANEL-ALMOND
010	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
011	Y330100		Not Available	COIN BOX ASSEMBLY
012	NLA		Not Available	LOCK
013	NLA		Not Available	FRONT PANEL-WHITE
014	330108L		Not Available	FRONT PANEL-ALMOND

015	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
016	Y330147			Part Not Used
017	330183		Not Available	TRANSFORMER
018	Y330192		Not Available	SWITCH, PUSH TO START
019	NLA		Not Available	SCREW - BRACKET TO VAULT
020	331012	400022-1		Screw
021	331014	8281196		Screw
022	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
023	331032	61002031		Screw, Handle
024	331036			Washer-Front Panel Screws
025	331041			Button-Push-To-Start Switch
026	331061			Knob For Temperature Contro
027	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
028	NLA		Not Available	SPACER - TEMP CONTROL COVER
029	NLA		Not Available	HINGE RIVET
030	NLA		Not Available	MOUNTING PLATE-TICKET CONT
031	NLA		Not Available	RETAINER-TICKET CONTROL
032	NLA		Not Available	SCREW-TEMP CONTROL LEVER
033	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
034	331151			Lever-Temperature Control
035	NLA		Not Available	NUT FOR CONDUIT
036	NLA		Not Available	TWIN FASTENER WITH SCREWS

the laundry company[®]

twos
the laundry company[®]