


# Maytag LDG34CD 03 - ELECTRONIC CONTROL ASSEMBLY

## MODEL DG34CD-CQ

### CD-CQ ELECTRONIC CONTROL ASSEMBLY



Maytag [Residential Maytag LDG34CD Dryer Parts](#) Parts Diagram 03 - ELECTRONIC CONTROL ASSEMBLY  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By             | Status        | Part Description             |
|------|--------------------------|-------------------------|---------------|------------------------------|
| 001  | Y310632                  | <a href="#">1163839</a> |               | Screw                        |
| 002  | Y330264                  |                         | Not Available | WIRE HARNESS                 |
| 003  | Y330265                  |                         | Not Available | WIRE HARNESS-DUAL CONTROL    |
| 004  | Y330266                  |                         | Not Available | MEMBRANE SWITCH              |
| 005  | Y330268                  |                         | Not Available | COIN ACCEPTOR ASSEMBLY \$.25 |
| 006  | NLA                      |                         | Not Available | COIN ACCEPTOR ASSEMBLY \$.10 |
| 007  | Y330270                  |                         | Not Available | COIN SWITCH                  |
| 008  | <a href="#">36001001</a> |                         |               | Printed Circuit Board        |
| "    | <a href="#">36001002</a> |                         |               | Sensor                       |
| "    | Y330273                  | <a href="#">Y330316</a> |               | Electronic                   |
| "    | <a href="#">Y330315</a>  |                         |               | Switch Assembly              |
| "    | Y330319                  |                         | Not Available | WIRE ASSEMBLY                |
| "    | <a href="#">Y330320</a>  |                         |               | Harness, Heat Sensor         |
| 009  | <a href="#">331233</a>   |                         |               | Plate For Electronic Contro  |

|     |                        |                        |                                    |
|-----|------------------------|------------------------|------------------------------------|
| 010 | <a href="#">331234</a> |                        | Spacer For Circuit Board           |
| 011 | 331235                 | <a href="#">701719</a> | Nut, Hex                           |
| 012 | NLA                    |                        | Not Available BAIL FOR COIN RETURN |
| 013 | <a href="#">331237</a> |                        | Screw                              |
| 014 | NLA                    |                        | Not Available LOCK WASHER          |
| 015 | NLA                    |                        | Not Available BUMPER               |
| 016 | NLA                    |                        | Not Available LABEL - \$.25        |
| 017 | NLA                    |                        | Not Available LABEL - \$.10-\$.25  |

