


Maytag LDG382 03 - FRONT VIEW



Maytag Residential Maytag LDG382 Dryer Parts Parts Diagram 03 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y052740	62739		Nut, Lock
2	204439			Screw And Fstner Assembly
3	204445			Screw And Fastener Assembly
4	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	213007			Xfor Cabinet See Cabinet, Back
7	302542L		Not Available	PART NOT USED. (DG ONLY)
9	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
10	303942		Not Available	KNOB AND SCREW
12	304594L		Not Available	FRONT PANEL-ALMOND
14	Y305086			Adjustable Leg And Nut
16	305190L	307104L		Top Cover Assembly
19	305193L			Console
22	305302L		Not Available	CABINET-ALMOND
25	306668L		Not Available	DOOR, ALMOND

27	Y310632	1163839	Screw
28	Y313559		Screw
30	313908L	Not Available	DOOR PANEL-ALMOND
32	Y314137		Foot, Rubber

