


Maytag LDG5004ABW 03 - CONTROL PANEL



Maytag Residential Maytag LDG5004ABW Dryer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	33001237		Not Available	PLATE, SUPPORT
3	314728	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	207927			End Cap, Control Panel
"	207928		Not Available	END CAP, CTRL. PNL. (LT-BLK)
"	22001562	22001290		End Cap, Control Panel
"	22001563	22001288		End Cap, Control Panel
5	214894			Fastener, End Cap
6	33001091		Not Available	PANEL, CONTROL (BLK)
7	33001182		Not Available	SKIRT, TIMER DIAL (BLK)
8	315041			Knob, Timer
9	312273			Nut, Control Knob
10	216193		Not Available	CAP, TIMER KNOB (BLK)
11	33001184			Button

12	214897		Pad, Control Panel
13	315317	488234	Screw 8-32 X 1/4
14	Y308218		Timer RPR
15	210186	3370225	Screw
16	204807		Ground Wire, Supp. Plte To Top Cover
17	315317	488234	Screw 8-32 X 1/4
18	Y308205	33001623	Buzzer, Non-Adjustable
19	315317	488234	Screw 8-32 X 1/4
20	33001232	Not Available	SWITCH, PUSH TO START
21	33001528		Harness, Wire
"	33001119		Harness, Wire
22	33001239	Not Available	MANUAL, USE & CARE (FRENCH)

the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]