


# Maytag LDG512 01 - CONTROL PANEL



Maytag [Residential Maytag LDG512 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
2	314177		Not Available	BRACKET FOR START SWITCH
3	<a href="#">306533</a>			Switch, Push/To/Start W/Bkt
4	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
5	<a href="#">314184</a>			Back Up Plate
6	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
7	<a href="#">214815</a>			End Cap F/Control Panel-LH
8	<a href="#">214894</a>			Fastener, End Cap
9	306384		Not Available	CONTROL PANEL
"	305884		Not Available	CONTROL PANEL
10	910708	<a href="#">488234</a>		Screw 8-32 X 1/4
11	314422	<a href="#">33001500</a>		Dial, Timer Indicator
12	<a href="#">314421</a>			Knob For Timer
13	<a href="#">312273</a>			Nut, Control Knob

14	215164		Not Available	CAP FOR KNOB
15	<a href="#">214816</a>			End Cap F/Control Panel-RH
16	<a href="#">214897</a>			Pad, Control Panel
17	<a href="#">306040</a>			Timer
18	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
19	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
20	<a href="#">215210</a>			Button For Switch
21	<a href="#">305963</a>			Temperature Switch
22	305205	<a href="#">694419</a>		Mini-Buzzer
23	305968		Not Available	WIRE HARNESS
"	306180		Not Available	MAIN WIRE HARNESS
"	306806		Not Available	WIRE HARNESS

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>