


# Maytag LDG6004AAW 01 - CABINET-FRONT



Maytag Residential Maytag LDG6004AAW Dryer Parts Parts Diagram 01 - CABINET-FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">Y305193</a>			Console
2	216423	<a href="#">3370225</a>		Screw
3	<a href="#">33001165</a>			Top Cover Assembly
4	<a href="#">33001242</a>			Panel, Front
5	<a href="#">33001241</a>			Handle, Door
6	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
7	<a href="#">33001230</a>			Hinge, Door
8	<a href="#">204439</a>			Screw And Fstner Assembly
9	<a href="#">215075</a>			Fastener, Control Panel To Console
10	<a href="#">Y313561</a>			Screw---NA
"	Y310632	<a href="#">1163839</a>		Screw
11	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
12	<a href="#">Y314137</a>			Foot, Rubber
13	<a href="#">Y305086</a>			Adjustable Leg And Nut
14	Y052740	<a href="#">62739</a>		Nut, Lock

15	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
16	33001159	<a href="#">33001327</a>	Cabinet
17	210186	<a href="#">3370225</a>	Screw
18	33001132	<a href="#">33002342</a>	Plug, Sifht Hole

