

# Maytag LDG6004AAW 04 - DOOR



Maytag [Residential Maytag LDG6004AAW Dryer Parts](#) Parts Diagram 04 - DOOR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
2	<a href="#">33001230</a>			Hinge, Door
3	<a href="#">33001240</a>			Door
4	<a href="#">33001241</a>			Handle, Door
5	<a href="#">33001131</a>			Seal, Door
6	33001132	<a href="#">33002342</a>		Plug, Sifht Hole
7	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
8	212982	<a href="#">22001650</a>		Fastener, Spring
9	<a href="#">Y310376</a>			Clip, Door Switch Harness
10	Y305753	<a href="#">W10169313</a>		Switch-Dor
"	33001509	<a href="#">W10169313</a>		Switch-Dor
11	<a href="#">314937</a>			Seal, Front Panel
12	33001173		Not Available	NUT, SPEED
"	33001172		Not Available	SCREW, PLASTIC
13	<a href="#">33001242</a>			Panel, Front
14	33001174	<a href="#">LA-1003</a>		Door Catch Kit

15	<a href="#">33001175</a>		Cover, Hinge Hole
16	<a href="#">Y313910</a>		Clip, Door Liner To Outer Panel
17	<a href="#">204439</a>		Screw And Fstner Assembly
18	33001243	Not Available	PANEL, INNER DOOR (W/SEAL)
19	<a href="#">33001305</a>		Strike, Door

