


Maytag LDG7304AGE 02 - CABINET-REAR



Maytag [Residential Maytag LDG7304AGE Dryer Parts](#) Parts Diagram 02 - CABINET-REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
2	Y313561			Screw---NA
4	Y310376			Clip, Door Switch Harness
11	33001285		Not Available	CORD, POWER
12	216183			Grommet, Cord Export
13	303846	22003781		Screw, Ground Strap
14	301548			Clamp, Ground Wire
15	204807			Ground Wire, Supp. Plte To Top Cover
16	Y313559			Screw
17	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
18	Y312951		Not Available	ACCESS COVER, BACK
19	Y305086			Adjustable Leg And Nut
20	Y314137			Foot, Rubber
21	Y052740	62739		Nut, Lock
22	Y302361		Not Available	BASE ASSY. (UPPER &

22

1303301

Not Available

LOWER)

23

[213007](#)

Xfor Cabinet See Cabinet,
Back

24

33001159

[33001327](#)

Cabinet

25

[Y313561](#)

Screw---NA

"

Y310632

[1163839](#)

Screw

