


Maytag LDG7304AGE 03 - CONTROL PANEL



Maytag Residential Maytag LDG7304AGE Dryer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	33001237		Not Available	PLATE, SUPPORT
3	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	22001565		Not Available	CAP, END (LT-WHT)
"	22001564			Cap, End
"	22001291			End Cap, Control Panel
"	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
5	214894			Fastener, End Cap
6	33001075			Panel, Control
7	33001183			Skirt, Timer Dial
8	33001255			Knob, Timer
9	312273			Nut, Control Knob
10	216250	22001446		Cap, Knob
11	33001185	33001187		Button

12	214897		Pad, Control Panel
13	315317	488234	Screw 8-32 X 1/4
14	33001037		Timer RPR
15	210186	3370225	Screw
16	204807		Ground Wire, Supp. Plte To Top Cover
17	315317	488234	Screw 8-32 X 1/4
18	305205	694419	Mini-Buzzer
19	315317	488234	Screw 8-32 X 1/4
20	33001232	Not Available	SWITCH, PUSH TO START
21	33001124		Harness, Wire---NA
"	33001552		Harness, Wire
"	33001366	Not Available	WIRE HARNESS, MAIN (240V-50HZ)
22	22001268	Not Available	KNOB ASSY. (WHT)
23	33001228	Not Available	SWITCH, TEMP. (3 POSITIONS)
24	22001215	7730P011-60	Lens, Indicator Light
25	33001223	Not Available	LIGHT, INDICATOR
26	33001256		Manual, Use And Care
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

