


Maytag LDG7304AGM 03 - CONTROL PANEL (LDE7304AGM & LDG7304AGM)



Maytag Residential Maytag LDG7304AGM Dryer Parts Parts Diagram 03 - CONTROL PANEL (LDE7304AGM & LDG7304AGM)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	33001237		Not Available	PLATE, SUPPORT
3	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	22001292	22001567		Cap, End
"	22001293			End Cap, Control Panel
"	22001566	22001293		End Cap, Control Panel
"	22001567			Cap, End
5	214894			Fastener, End Cap
6	33001472		Not Available	PANEL, CONTROL (ALM)
7	33001372		Not Available	SKIRT, TIMER DIAL (ALM)
8	33001282	33002325		Knob Assembly
9	312273			Nut, Control Knob
10	216424		Not Available	CAP, KNOB (ALM)

11	33001371		Button, Push-To-Start
12	214897		Pad, Control Panel
13	315317	488234	Screw 8-32 X 1/4
14	33001037		Timer RPR
15	210186	3370225	Screw
16	204807		Ground Wire, Supp. Plte To Top Cover
17	315317	488234	Screw 8-32 X 1/4
18	305205	694419	Mini-Buzzer
19	315317	488234	Screw 8-32 X 1/4
20	33001232	Not Available	SWITCH, PUSH TO START
21	33001552		Harness, Wire
"	33001366	Not Available	WIRE HARNESS, MAIN (240V-50HZ)
22	22001269	Not Available	KNOB ASSY. (ALM)
23	33001228	Not Available	SWITCH, TEMP. (3 POSITIONS)
24	22001215	7730P011-60	Lens, Indicator Light
25	33001223	Not Available	LIGHT, INDICATOR
26	33001256		Manual, Use And Care
"	16000327	Not Available	GUIDE, QUICK REF. - MAYTAG

