


Maytag LDG7304AGM 04 - DOOR (LDE7304AGM & LDG7304AGM)



Maytag Residential Maytag LDG7304AGM Dryer Parts Parts Diagram 04 - DOOR (LDE7304AGM & LDG7304AGM)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y314062			Screw, Door Hinge And Panel
2	33001230			Hinge, Door
3	33001257	33001240		Door
4	33001254	37001047		Handle, Door
5	33001131			Seal, Door
6	33001168		Not Available	PLUG, SIGHT HOLE (ALM)
7	Y304578	LA-1003		Door Catch Kit
8	212982	22001650		Fastener, Spring
9	Y310376			Clip, Door Switch Harness
10	Y305754	W10169313		Switch-Dor
"	33001508	W10169313		Switch-Dor
11	314937			Seal, Front Panel
12	33001173		Not Available	NUT, SPEED
"	33001172		Not Available	SCREW, PLASTIC
13	33001258	33001242		Panel, Front
14	33001174	LA-1003		Door Catch Kit

15	33001176		Cover, Hinge Hole
16	Y313910		Clip, Door Liner To Outer Panel
17	204439		Screw And Fstner Assembly
18	33001243	Not Available	PANEL, INNER DOOR (W/SEAL)
19	33001305		Strike, Door

