


Maytag LDG7304EGE 01 - CABINET-FRONT



Maytag Residential Maytag LDG7304EGE Dryer Parts Parts Diagram 01 - CABINET-FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y305193			Console
2	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313559			Screw
3	33001165			Top Cover Assembly
4	33001242			Panel, Front
5	33001241			Handle, Door
6	214354			Screw, Top Cover To Cabnt.
7	33001230			Hinge, Door
8	204439			Screw And Fstner Assembly
9	215075			Fastener, Control Panel To Console
10	Y313561			Screw---NA
"	Y310632	1163839		Screw
11	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
12	Y314137			Foot, Rubber

13	Y305086		Adjustable Leg And Nut
14	Y052740	62739	Nut, Lock
15	213007		Xfor Cabinet See Cabinet, Back
16	33001159	33001327	Cabinet
17	210186	3370225	Screw
18	33001132	33002342	Plug, Sifht Hole

