

# Maytag LDG7400ABL 02 - CABINET-REAR



Maytag Residential Maytag LDG7400ABL Dryer Parts Parts Diagram 02 - CABINET-REAR  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
2	<a href="#">Y313561</a>			Screw----NA
3	311484	<a href="#">112432</a>		Nut
4	<a href="#">Y312184</a>			Strap, Grounding
5	<a href="#">400008</a>			Block, Terminal
6	<a href="#">Y312904</a>			Bracket, Terminal Block
7	Y312209	<a href="#">W10001200</a>		Screw
8	<a href="#">Y311270</a>			Washer, Terminal Block
9	Y310632	<a href="#">1163839</a>		Screw
10	Y311423	<a href="#">489483</a>		Screw 10-32 X 1/2
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
12	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
13	<a href="#">215075</a>			Fastener, Control Panel To Console
14	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct

15	<a href="#">305193L</a>		Console
16	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
17	303846	<a href="#">22003781</a>	Screw, Ground Strap
18	<a href="#">301548</a>		Clamp, Ground Wire
19	<a href="#">311155</a>		Ground Wire And Clamp
20	<a href="#">Y313559</a>		Screw
21	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	<a href="#">Y305086</a>		Adjustable Leg And Nut
24	<a href="#">Y314137</a>		Foot, Rubber
25	Y052740	<a href="#">62739</a>	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	213077	Not Available	CAP FOR TIMER KNOB
28	307124L	Not Available	CABINET ASSY ALMOND
29	<a href="#">307104L</a>		Top Cover Assembly

