


Maytag LDG7480ABL 01 - CABINET-FRONT



4

Maytag Residential Maytag LDG7480ABL Dryer Parts Parts Diagram 01 - CABINET-FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	305193L			Console
2	Y313559			Screw
3	307104L			Top Cover Assembly
4	307998L			Front Panel----NA
5	314972			Handle Door ALM
6	314966L		Not Available	DOOR PANEL ALMOND
"	307111L	308061L		Door Assembly----NA
7	307099	33001230		Hinge, Door
8	204439			Screw And Fstner Assembly
9	302542L		Not Available	PART NOT USED. (DG ONLY)
10	Y310632	1163839		Screw
11	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
12	Y314137			Foot, Rubber
13	Y305086			Adjustable Leg And Nut
14	Y052740	62739		Nut, Lock
15				Yfor Cabinet See Cabinet

15	213007		Ator Cabinet See Cabinet, Back
16	307124L	Not Available	CABINET ASSY ALMOND
17	204445		Screw And Fastener Assembly
18	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping

