


Maytag LDG7480ABL 03 - CONTROL PANEL



2

Maytag Residential Maytag LDG7480ABL Dryer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	314184			Back Up Plate
3	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	207928		Not Available	END CAP, CTRL. PNL. (LT-BLK)
5	214894			Fastener, End Cap
6	308521		Not Available	PANEL, CONTROL
7	315042			Dial Skirt
8	315041			Knob, Timer
9	312273			Nut, Control Knob
10	215821		Not Available	CAP, KNOB
11	207927			End Cap, Control Panel
12	214897			Pad, Control Panel
13	315317	488234		Screw 8-32 X 1/4
14	Y308218			Timer RPR

15	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
16	204807		Ground Wire, Supp. Plte To Top Cover
17	211168	W10139210	Screw, 8-18 X 5/16
18	305205	694419	Mini-Buzzer
19	307305		Switch Push To Start
20	308334	Not Available	WIRE HARNESS
"	Y308498		Harness, Wire

