


Maytag LDG7480ABW 02 - CABINET-REAR



6

Maytag Residential Maytag LDG7480ABW Dryer Parts Parts Diagram 02 - CABINET-REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
2	Y313561			Screw---NA
9	Y310632	1163839		Screw
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
12	211881			Grommet, Cord Part Not Used-Gas Models Only
13	215075			Fastener, Control Panel To Console
14	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
15	Y305193			Console
16	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
17	303846	22003781		Screw, Ground Strap
18	301548			Clamp, Ground Wire
19	311155			Ground Wire And Clamp
20	Y313559			Screw

21	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	Y305086		Adjustable Leg And Nut
24	Y314137		Foot, Rubber
25	Y052740	62739	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	213077	Not Available	CAP FOR TIMER KNOB

