


# Maytag LDG7480ABW 03 - CONTROL PANEL



2

Maytag [Residential Maytag LDG7480ABW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
2	<a href="#">314184</a>			Back Up Plate
3	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	207928		Not Available	END CAP, CTRL. PNL. (LT-BLK)
5	<a href="#">214894</a>			Fastener, End Cap
6	308521		Not Available	PANEL, CONTROL
7	<a href="#">315042</a>			Dial Skirt
8	<a href="#">315041</a>			Knob, Timer
9	<a href="#">312273</a>			Nut, Control Knob
10	215821		Not Available	CAP, KNOB
11	<a href="#">207927</a>			End Cap, Control Panel
12	<a href="#">214897</a>			Pad, Control Panel
13	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
14	<a href="#">Y308218</a>			Timer RPR

15	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
16	<a href="#">204807</a>		Ground Wire, Supp. Plte To Top Cover
17	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
18	305205	<a href="#">694419</a>	Mini-Buzzer
19	<a href="#">307305</a>		Switch Push To Start
20	308334	Not Available	WIRE HARNESS
"	<a href="#">Y308498</a>		Harness, Wire

