


Maytag LDG7480ABW 04 - DOOR



8

Maytag [Residential Maytag LDG7480ABW Dryer Parts](#) Parts Diagram 04 - DOOR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y314062			Screw, Door Hinge And Panel
2	307099	33001230		Hinge, Door
3	314966			Panel, Outer
4	314946			Handle White
5	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
6	312960	489355		Screw, 8 X 1/2
7	306436			Door Latch Kit-W
8	212982	22001650		Fastener, Spring
9	Y310376			Clip, Door Switch Harness
10	Y305753	W10169313		Switch-Dor
11	314937			Seal, Front Panel
12	Y313907			Fastener, Twin
13	Y307998			Front Panel
14	312301		Not Available	BUSHING FOR ACCESS STUD
15	312360			Sleeve, Access Panel Stud

15	312309		Part Not Used
16	212949	22001866	Screw, Relay
17	204439		Screw And Fstner Assembly
18	302542		Not Available
19	314936	33001305	Strike, Door
20	314935	33001192	Seal, Door
21	307098		Not Available
22	315441		Not Available
"	Y313910		Clip, Door Liner To Outer Panel
"	314941		Not Available
			LABEL, INSTRUCTION

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®