


Maytag LDG7600AGG 10 - TUMBLER

Section: TUMBLER

P/N 1600028

Models: ALL MODELS



5/93

Maytag [Residential Maytag LDG7600AGG Dryer Parts](#) Parts Diagram 10 - TUMBLER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y307112	33001016		Outlet Duct Assembly
2	Y307107	33002970		Lint Filte
"	307213	33001167		Filter, Lint
3	313764		Not Available	SCREW
4	Y313561			Screw---NA
5	307117			Tumbler Front W/Seal
"	307109	33001179		Front, Tumbler
"	307311	33001179		Front, Tumbler
6	Y310376			Clip, Door Switch Harness
7	Y307100	67001316		Bulb, Light
8	314955	33001496		Lamp- Hold
9	307097	33001496		Lamp- Hold
10	314820			Seal, Tumbler
11	314803	33001012		Baffle
12	314158			Washer, Baffle To Tumbler
13	314802		Not Available	TUMBLER W/OUT BAFFLES

		Not Available	TUMBLER W/BAFFLES
"	306663		
14	Y310759		Screw, Tumbler Baffles
15	Y307114	33001178	Back, Tumbler
"	Y308544	33001178	Back, Tumbler
16	313915	31-3915	Tech Sheet
17	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
18	312538	33001443	Nut, Hex
19	Y313347	312535	Washer, Vault Mounting Brk.
20	Y312948	6-3129480	Shaft- Tumbler
21	Y303373	12001541	Drum Roller/Washer Assembly--W
22	312535		Washer, Vault Mounting Brk.
23	410233	9703438	Ring-Retrn
24	Y312959		Poly "V" Belt For Tumbler
25	314804	33001004	Baffle, Tall
26	Y314110	33002917	Screw, No.10-16
27	210720		Rivet, Bearing To Tumbler Fmt
28	306508		Tumbler Bearing Kit ---W
29	Y310632	1163839	Screw
30	315020		Switch Housing
31	307206	307207	Reed Switch
32	Y251119	3177991	Screw
33	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
34	Y303711		Sensor Ground Wire
35	304997		Sensor Assembly With Screws
36	Y312658		Receptacle, Sensor Ground Wire

the laundry company[®]

the laundry company[®]