

Maytag LDG8420ABW 02 - CABINET-REAR



Maytag Residential Maytag LDG8420ABW Dryer Parts Parts Diagram 02 - CABINET-REAR
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
2	Y313561			Screw----NA
3	311484	112432		Nut
4	Y312184			Strap, Grounding
5	400008			Block, Terminal
6	Y312904			Bracket, Terminal Block
7	Y312209	W10001200		Screw
8	Y311270			Washer, Terminal Block
9	Y310632	1163839		Screw
10	Y311423	489483		Screw 10-32 X 1/2
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
12	211881			Grommet, Cord Part Not Used-Gas Models Only
13	215075			Fastener, Control Panel To Console
14	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct

15	Y305193		Console
16	214519		LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
17	303846	22003781	Screw, Ground Strap
18	301548		Clamp, Ground Wire
19	311155		Ground Wire And Clamp
20	Y313559		Screw
21	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	Y305086		Adjustable Leg And Nut
24	Y314137		Foot, Rubber
25	Y052740	62739	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	213077	Not Available	CAP FOR TIMER KNOB
28	307124		Cabinet
29	307104		Top Cover Assembly

