


Maytag LDG8424AAL 02 - CABINET-REAR



Maytag [Residential Maytag LDG8424AAL Dryer Parts](#) Parts Diagram 02 - CABINET-REAR
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|--------------------------|---------------|---|
| 1 | Y312905 | | Not Available | COVER, TERMINAL |
| 2 | 33001246 | | Not Available | CORD, POWER |
| 3 | 211881 | | | Grommet, Cord Part Not Used- Gas Models Only |
| 4 | 303846 | 22003781 | | Screw, Ground Strap |
| 5 | 301548 | | | Clamp, Ground Wire |
| 6 | 204807 | | | Ground Wire, Supp. Plte To Top Cover |
| 7 | Y313559 | | | Screw |
| 8 | 211294 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 9 | Y312951 | | Not Available | ACCESS COVER, BACK |
| 10 | Y305086 | | | Adjustable Leg And Nut |
| 11 | Y314137 | | | Foot, Rubber |
| 12 | Y052740 | 62739 | | Nut, Lock |
| 13 | Y303361 | | Not Available | BASE ASSY. (UPPER & LOWER) |
| 14 | 213007 | | | Xfor Cabinet See Cabinet, |

| | | | |
|----|-------------------------|-------------------------|---------------------------|
| 14 | Z13007 | | Back |
| 15 | 33001160 | Not Available | CABINET (ALM) |
| 16 | Y313561 | | Screw---NA |
| " | Y310632 | 1163839 | Screw |
| 17 | Y310376 | | Clip, Door Switch Harness |
| 18 | Y313561 | | Screw---NA |

