


# Maytag LDG8426EGE 03 - CONTROL PANEL



Maytag Residential Maytag LDG8426EGE Dryer Parts Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33001590</a>			Panel, Control
"	22001662	<a href="#">8534058</a>		Screw
2	<a href="#">33001621</a>			Skirt, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">22001664</a>			Timer Knob Insert/Cap
5	33001619	<a href="#">37001071</a>		Button, Push-To-Start
6	33001690	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	<a href="#">33001636</a>			Timer
8	210186	<a href="#">3370225</a>		Screw
9	<a href="#">22001654</a>			Wire, Ground
10	216423	<a href="#">3370225</a>		Screw
11	305205	<a href="#">694419</a>		Mini-Buzzer
12	33001726	<a href="#">33001618</a>		Switch- PU
13	<a href="#">33001677</a>			Wire Harness, Main
14	<a href="#">22001663</a>			Knob, Selector Switch
15	<a href="#">33001639</a>			Switch, Temperature

