


Maytag LDG8824AAE 03 - CONTROL PANEL



Maytag Residential Maytag LDG8824AAE Dryer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	214872			Palnut, End Cap Note: Nut, Lamp Holder
2	33001265			Plate, Support
3	210932			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	22001289		Not Available	END CAP, CTRL. PNL. (LT-WHT)
"	22001565		Not Available	CAP, END (LT-WHT)
"	22001564			Cap, End
"	22001291			End Cap, Control Panel
5	214894			Fastener, End Cap
6	33001062			Panel, Control
7	33001183			Skirt, Timer Dial
8	33001255			Knob, Timer
9	312273			Nut, Control Knob
10	216250	22001446		Cap, Knob
11	33001187			Button

12	214897		Pad, Control Panel
13	315317	488234	Screw 8-32 X 1/4
14	33001035		Timer
15	210186	3370225	Screw
16	204807		Ground Wire, Supp. Plte To Top Cover
17	315317	488234	Screw 8-32 X 1/4
18	Y308205	33001623	Buzzer, Non-Adjustable
19	315317	488234	Screw 8-32 X 1/4
20	33001232	Not Available	SWITCH, PUSH TO START
21	33001542	Not Available	HARNESS, WIRE
"	33001137	Not Available	WIRE HARNESS, MAIN
"	33001347	Not Available	WIRE HARNESS, MAIN
22	22001135		Switch, Rocker
23	33001214	Not Available	SWITCH, PUSH BUTTON ---- NA
24	315317	488234	Screw 8-32 X 1/4
25	33001047		Display, Dryness Assembly
26	33001212		Board, Control-Moisture Sensor
27	315317	488234	Screw 8-32 X 1/4
28	33001218	33001219	Switch, Push Button
29	33001105		Resistor

