


# Maytag LDG9701AAL 02 - CABINET-REAR



8

Maytag [Residential Maytag LDG9701AAL Dryer Parts](#) Parts Diagram 02 - CABINET-REAR  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312905		Not Available	COVER, TERMINAL
2	<a href="#">Y313561</a>			Screw---NA
9	Y310632	<a href="#">1163839</a>		Screw
11	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
12	<a href="#">211881</a>			Grommet, Cord Part Not Used-Gas Models Only
13	<a href="#">215075</a>			Fastener, Control Panel To Console
14	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
15	<a href="#">305193L</a>			Console
"	<a href="#">Y305193</a>			Console
16	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
17	303846	<a href="#">22003781</a>		Screw, Ground Strap
18	<a href="#">301548</a>			Clamp, Ground Wire
19	<a href="#">311155</a>			Ground Wire And Clamp

20	<a href="#">Y313559</a>		Screw
21	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
22	Y312951	Not Available	ACCESS COVER, BACK
23	<a href="#">Y305086</a>		Adjustable Leg And Nut
24	<a href="#">Y314137</a>		Foot, Rubber
25	Y052740	<a href="#">62739</a>	Nut, Lock
26	Y303361	Not Available	BASE ASSY. (UPPER & LOWER)
27	213077	Not Available	CAP FOR TIMER KNOB
28	<a href="#">307124</a>		Cabinet
"	307124L	Not Available	CABINET ASSY ALMOND
29	<a href="#">307104</a>		Top Cover Assembly
"	<a href="#">307104L</a>		Top Cover Assembly

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>