


# Maytag LDG9701ABL 03 - CONTROL PANEL



6

Maytag Residential Maytag LDG9701ABL Dryer Parts Parts Diagram 03 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">214872</a>			Palnut, End Cap Note: Nut, Lamp Holder
2	<a href="#">314184</a>			Back Up Plate
3	<a href="#">210932</a>			Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
4	207215		Not Available	END CAP LH
5	<a href="#">214894</a>			Fastener, End Cap
6	308189		Not Available	CONTROL PANEL
7	<a href="#">315042</a>			Dial Skirt
8	<a href="#">315041</a>			Knob, Timer
9	<a href="#">312273</a>			Nut, Control Knob
10	215821		Not Available	CAP, KNOB
11	207216		Not Available	END CAP RH
12	<a href="#">214897</a>			Pad, Control Panel
13	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
14	<a href="#">Y308188</a>			Timer
15	211204	<a href="#">00767</a>		Screw, 8A X 3/8 HeX Washer

15	<a href="#">211294</a>	<a href="#">30707</a>		Head Tapping
16	<a href="#">204807</a>			Ground Wire, Supp. Plte To Top Cover
17	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
18	Y308205	<a href="#">33001623</a>		Buzzer, Non-Adjustable
19	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
20	<a href="#">306917</a>			Resistor, Med Temp Gas
21	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
22	213117	<a href="#">67006908</a>		Screw, Ice Rack
23	<a href="#">307305</a>			Switch Push To Start
24	Y308110	<a href="#">33001212</a>		Board, Control-Moisture Sensor
25	Y251119	<a href="#">3177991</a>		Screw
26	308186		Not Available	WIRE HARNESS
"	308505		Not Available	HARNESS, WIRE
27	<a href="#">307310</a>			Press Care Switch

