


Maytag LNC7766A71 02 - CONTROL PANEL



Maytag Residential Maytag LNC7766A71 Dryer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001382			Panel, Control
2	21001546			Endcap, Panel
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001547			Endcap, Panel
4	31001397			Buzzer
5	31001388			Knob/Skirt, Timer
6	25-7851			Speedclip, End Cap To Top
7	21001552			Frame , Control Panel
8	21001527			Shield, Rear
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	63-6743	31001484		Resistor Assembly
"	53-1815	31001513		Timer
10	21001517			Shield, Control

11 [21001544](#)
12 31001348 [31001449](#)
13 [31001190](#)

Knob, Selector
Switch, Selector
Switch, Two Position Rotary

