


# Maytag LNC8766A71 02 - CONTROL PANEL



Maytag Residential Maytag LNC8766A71 Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">31001382</a>			Panel, Control
2	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001546</a>			Endcap, Panel
3	<a href="#">21001547</a>			Endcap, Panel
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">31001397</a>			Buzzer
5	<a href="#">31001388</a>			Knob/Skirt, Timer
6	<a href="#">25-7851</a>			Speedclip, End Cap To Top
7	<a href="#">21001552</a>			Frame , Control Panel
8	<a href="#">21001527</a>			Shield, Rear
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
9	53-1815	<a href="#">31001513</a>		Timer
10	<a href="#">21001517</a>			Shield, Control
11	<a href="#">21001544</a>			Knob, Selector

