


# Maytag LSE7800AEW 04 - CABINET (LSE7800AEL,AEW)



24

Maytag Residential Maytag LSE7800AEW Stacked Washer and Dryer Parts Parts Diagram 04 - CABINET (LSE7800AEL,AEW)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">210866</a>			Nut, Twin Speed
2	<a href="#">211500</a>			Washer, Bracket To Top Cover
3	<a href="#">213501</a>			Screw, No.6-20 X 1-1/8 Inch
4	<a href="#">202476</a>			Unbalance Switch
5	<a href="#">207797</a>			Relay
6	<a href="#">215273</a>			Clip, Spring Relay
7	207834	<a href="#">8566493</a>		Power Relay
8	<a href="#">208213</a>			Wire Harness
9	212949	<a href="#">22001866</a>		Screw, Relay
10	207207		Not Available	CABINET WHT
11	<a href="#">216017</a>			Hose, Drain
12	200908	<a href="#">285655</a>		Clamp, Hose
13	<a href="#">Y014874</a>			Screw, Idler Arm And Sleeve
14	Y216016	<a href="#">W10116738</a>		Elbow
15	<a href="#">214765</a>			Gasket, Siphon Break
16	<a href="#">206638</a>			Siphon Break

17	202574	<a href="#">3367052</a>	Clamp, Hose
18	215365	<a href="#">22001448</a>	Hose, Pump
19	<a href="#">215711</a>		Fastener, Spring
20	<a href="#">207205</a>		Panel, Front
21	213123	<a href="#">22001496</a>	Front Panel Fastener And Screw
22	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
23	<a href="#">213846</a>		Guard, Belt
24	213122	<a href="#">27001200</a>	Screw
25	213280	<a href="#">204439</a>	Screw And Fstner Assembly
26	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
27	207787	<a href="#">12002304</a>	Switch-WL
28	<a href="#">214354</a>		Screw, Top Cover To Cabnt.
29	Y312209	<a href="#">W10001200</a>	Screw
30	<a href="#">Y312184</a>		Strap, Grounding
31	Y310632	<a href="#">1163839</a>	Screw
32	<a href="#">Y312904</a>		Bracket, Terminal Block
33	<a href="#">Y313561</a>		Screw----NA
34	<a href="#">400008</a>		Block, Terminal
35	<a href="#">Y311270</a>		Washer, Terminal Block
36	311484	<a href="#">112432</a>	Nut

