


# Maytag LSE7800AGE 09 - FRONT PANEL & CONTROL PANEL



Maytag Residential Maytag LSE7800AGE Stacked Washer and Dryer Parts Parts Diagram 09 - FRONT PANEL & CONTROL PANEL

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314286</a>			Seal For Front Panel
2	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
3	Y305753	<a href="#">W10169313</a>		Switch-Dor
4	315261		Not Available	FRONT PANEL (WHITE)
5	<a href="#">Y310376</a>			Clip, Door Switch Harness
6	<a href="#">315287</a>			Bumper Small
7	<a href="#">306436</a>			Door Latch Kit-W
8	<a href="#">308017</a>			Switch, Dryer Temperature
9	213966	<a href="#">3400014</a>		Screw
10	<a href="#">207782</a>			Switch, Water Temperature
11	<a href="#">207800</a>			Switch, Water Level
12	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
13	<a href="#">208085</a>			Timer, Dial
14	<a href="#">315423</a>			End Cap, Control Panel
15	211000			SCREW, BRAKE DRUM (HEX

15	211000		HEAD)
16	<a href="#">211065</a>		Spring, Index Wheel
17	216055	Not Available	CONTROL KNOB
18	216057	Not Available	CAP, KNOB
19	<a href="#">211605</a>		Bezel, Timer Dial
20	<a href="#">312273</a>		Nut, Control Knob
21	315422	<a href="#">33001255</a>	Knob, Timer
22	Y308453	<a href="#">22001663</a>	Knob, Selector Switch
23	<a href="#">308451</a>		Timer Dial Dryer
24	<a href="#">215952</a>		Screw
25	Y308449	<a href="#">Y308025</a>	Switch, Push To Start
26	308454	<a href="#">3149401</a>	Switch-Inf
27	<a href="#">215952</a>		Screw
28	<a href="#">315237</a>		Bracket For Switch And Timer
29	<a href="#">Y308563</a>		Timer
30	<a href="#">314482</a>		Fastener, Spring
31	314748	<a href="#">488660</a>	Nut, Speed
32	<a href="#">315286</a>		Bumper Large
33	<a href="#">208229</a>		Timer
34	215960	Not Available	STRAIN RELIEF
35	308338	<a href="#">308643</a>	Kit- Harness
"	208232	Not Available	HARNESS, WIRE
36	215948	Not Available	GROMMET
37	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
38	216008	Not Available	BRACKET GROMMET
39	<a href="#">207945</a>		Wire Harness Upper

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>