


# Maytag LSE7804ACE 08 - FRONT PANEL & CONTROL PANEL



Maytag Residential Maytag LSE7804ACE Stacked Washer and Dryer Parts Parts Diagram 08 - FRONT PANEL & CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314286</a>			Seal For Front Panel
2	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
3	Y305753	<a href="#">W10169313</a>		Switch-Dor
"	33001509	<a href="#">W10169313</a>		Switch-Dor
4	33001486	<a href="#">98008544</a>		Screw
"	<a href="#">33001191</a>			Panel, Front
5	<a href="#">Y310376</a>			Clip, Door Switch Harness
6	<a href="#">315287</a>			Bumper Small
7	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
8	<a href="#">308017</a>			Switch, Dryer Temperature
9	216042	<a href="#">22001627</a>		Screw
10	<a href="#">207782</a>			Switch, Water Temperature
11	<a href="#">22001188</a>			Switch, Rotary
12	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
13	22001035		Not Available	DIAL, TIMER (WHT)

14	<a href="#">315423</a>		End Cap, Control Panel
15	211000		SCREW, BRAKE DRUM (HEX HEAD)
16	<a href="#">211065</a>		Spring, Index Wheel
17	22001198	Not Available	KNOB, TIMER (WHT)
18	216250	<a href="#">22001446</a>	Cap, Knob
19	<a href="#">211605</a>		Bezel, Timer Dial
20	<a href="#">312273</a>		Nut, Control Knob
21	<a href="#">33001255</a>		Knob, Timer
22	Y308453	<a href="#">22001663</a>	Knob, Selector Switch
23	<a href="#">33001010</a>		Dial, Dryer Timer
24	315317	<a href="#">488234</a>	Screw 8-32 X 1/4
25	Y308449	<a href="#">Y308025</a>	Switch, Push To Start
26	33001007	Not Available	PANEL, CONTROL (WHT)
27	<a href="#">215952</a>		Screw
28	<a href="#">315237</a>		Bracket For Switch And Timer
29	<a href="#">33001034</a>		Timer, Dryer
30	<a href="#">314482</a>		Fastener, Spring
31	33001292	<a href="#">488660</a>	Nut, Speed
32	<a href="#">315286</a>		Bumper Large
33	<a href="#">22001180</a>		Timer
34	22001427	Not Available	WIRE HARNESS (UPR) NA
"	<a href="#">208772</a>		Wire Harness
35	<a href="#">22001585</a>		Harness, Wire
"	<a href="#">22001432</a>		Wire Harness
"	208776	Not Available	WIRE HARNESS (LOWER)
36	<a href="#">22004233</a>		Wire Harness
"	<a href="#">33001042</a>		Wire Harness, Dryer
"	<a href="#">33001368</a>		Wire Harness, Dryer
"	<a href="#">33001553</a>		Harness, Wire

