


# Maytag LSE7804ACE 11 - TOP & LID



Maytag Residential Maytag LSE7804ACE Stacked Washer and Dryer Parts Parts Diagram 11 - TOP & LID  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	208776		Not Available	WIRE HARNESS (LOWER)
"	<a href="#">22001585</a>			Harness, Wire
"	<a href="#">208772</a>			Wire Harness
"	<a href="#">22001432</a>			Wire Harness
"	22001427		Not Available	WIRE HARNESS (UPR) NA
2	<a href="#">208781</a>			Wire Harness, Lid Switch
"	<a href="#">22001443</a>			Harness, Wire
3	<a href="#">22001194</a>			Clip, Spring
4	<a href="#">22001001</a>			Screw
5	<a href="#">208823</a>			Pc Switch, Lid
6	22001251	<a href="#">12001513</a>		Switch-Lid
"	22001444	<a href="#">12001513</a>		Switch-Lid
"	22001581	<a href="#">12001514</a>		Switch-Lid
7	22001080		Not Available	LID (WHT)
8	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
9	22001064		Not Available	COVER, TOP (WHT)

10	<a href="#">212716</a>		Bumper, Lid
11	215579	<a href="#">215580</a>	Cup, Bleach
12	215374	Not Available	GASKET FOR BLEACH CUP
13	<a href="#">22001189</a>		Rod, Restraint
14	<a href="#">22001208</a>		Rod, Counter Balance
15	<a href="#">Y216184</a>		Spring, Counter Balance
16	<a href="#">22001193</a>		Bearing, Counter Balance
17	<a href="#">207166</a>		Switch, Check
18	<a href="#">22001283</a>		Trigger
19	<a href="#">215537</a>		Screw
"	<a href="#">22001183</a>		Screw
20	<a href="#">22001285</a>		Holder, Switch
21	<a href="#">22001286</a>		Switch, Arm
22	<a href="#">22001287</a>		Spring, Switch
23	<a href="#">22001250</a>		Glide, Switch Arm

