


# Maytag LSE7804ADM 03 - CABINET-DRYER (LSE7804ACM & ADM)



Maytag Residential Maytag LSE7804ADM Stacked Washer and Dryer Parts Diagram 03 - CABINET-DRYER (LSE7804ACM & ADM)

[Click on the part number to view part](#)

| Item | Original Part Number     | Replaced By               | Status        | Part Description               |
|------|--------------------------|---------------------------|---------------|--------------------------------|
| 1    | 303846                   | <a href="#">22003781</a>  |               | Screw, Ground Strap            |
| 2    | 314663                   | <a href="#">214354</a>    |               | Screw, Top Cover To Cabnt.     |
| 3    | <a href="#">Y313561</a>  |                           |               | Screw----NA                    |
| 4    | 314470                   |                           | Not Available | COVER, TERMINAL                |
| 5    | 308055L                  |                           | Not Available | CABINET (ALM)                  |
| 6    | <a href="#">312548</a>   |                           |               | Fastener-Access Panel To CA    |
| 7    | Y308205                  | <a href="#">33001623</a>  |               | Buzzer, Non-Adjustable         |
| 8    | <a href="#">400008</a>   |                           |               | Block, Terminal                |
| 9    | 211168                   | <a href="#">W10139210</a> |               | Screw, 8-18 X 5/16             |
| 10   | <a href="#">33001212</a> |                           |               | Board, Control-Moisture Sensor |
| 11   | 306128                   |                           | Not Available | BRACE FOR STAND-ACCESSORY      |
| 12   | 315264                   | <a href="#">74006784</a>  |               | Clip, Harness                  |
| 13   | 22001195                 | <a href="#">22002595</a>  |               | Bumper                         |
| 14   | Y310632                  | <a href="#">1163839</a>   |               | Screw                          |

|    |                          |                           |  |
|----|--------------------------|---------------------------|--|
| 15 | <a href="#">314489</a>   |                           | Guide, Pin                             |
| 16 | <a href="#">214872</a>   |                           | Palnut, End Cap Note: Nut, Lamp Holder |
| 17 | Y313262                  | <a href="#">W10116752</a> | Retainer-                              |
| 18 | 315471                   | <a href="#">22003298</a>  | Retainer, Wire                         |
| 19 | <a href="#">33001553</a> |                           | Harness, Wire                          |
| "  | <a href="#">33001368</a> |                           | Wire Harness, Dryer                    |
| "  | 22001426                 | Not Available             | WIRE HARNESS (UPR. CANADA)             |
| 20 | <a href="#">314477</a>   |                           | Screw, Access Panel                    |
| 21 | 33001051                 | <a href="#">33002365</a>  | Panel- Acc                             |
| "  | <a href="#">33001130</a> |                           | Shield, Reflective                     |
| 22 | <a href="#">314482</a>   |                           | Fastener, Spring                       |
| 23 | <a href="#">314498</a>   |                           | Pad, Dryer Leg                         |
| 24 | 33001294                 | <a href="#">33002361</a>  | Leg Assembly ----NA                    |
| 25 | Y052740                  | <a href="#">62739</a>     | Nut, Lock                              |
| 26 | <a href="#">Y314137</a>  |                           | Foot, Rubber                           |
| 27 | <a href="#">Y305086</a>  |                           | Adjustable Leg And Nut                 |
| 28 | <a href="#">210684</a>   |                           | Foot, Adjustable Leg                   |
| 29 | Y302699                  | <a href="#">22003428</a>  | Leg, Adjustable                        |
| 30 | <a href="#">Y052721</a>  |                           | Nut, Terminal Block Plate              |
| 31 | <a href="#">210385</a>   |                           | Lock Nut For Adjustable Leg            |
| 32 | 314499                   | Not Available             | BRACE                                  |
| 33 | <a href="#">214354</a>   |                           | Screw, Top Cover To Cabnt.             |
| 34 | 306110L                  | <a href="#">33002516</a>  | Stand, Dryer                           |
| 35 | 33001296                 | <a href="#">33002362</a>  | Leg Assembly ----NA                    |
| 36 | Y312209                  | <a href="#">W10001200</a> | Screw                                  |
| 37 | <a href="#">Y312904</a>  |                           | Bracket, Terminal Block                |
| 38 | 311484                   | <a href="#">112432</a>    | Nut                                    |
| 39 | <a href="#">33001245</a> |                           | Screw----NA                            |
| 40 | Y310632                  | <a href="#">1163839</a>   | Screw                                  |
| 41 | <a href="#">Y312184</a>  |                           | Strap, Grounding                       |
| 42 | <a href="#">Y311270</a>  |                           | Washer, Terminal Block                 |
| 43 | Y251119                  | <a href="#">3177991</a>   | Screw                                  |
| 44 | 305168                   | <a href="#">33002916</a>  | Power Cord, Canadian 240V              |
| "  | <a href="#">33001425</a> |                           | Locknut, Eared For Canadian            |

