


Maytag LSE7804ADM 07 - FRONT PANEL & CONTROL PANEL (7804ACM &



Maytag Residential Maytag LSE7804ADM Stacked Washer and Dryer Parts Parts Diagram 07 - FRONT PANEL & CONTROL PANEL (7804ACM & Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314286			Seal For Front Panel
2	212277			Screw, No.8 X 1/2 Inch
3	33001509	W10169313		Switch-Dor
"	Y305753	W10169313		Switch-Dor
4	33001486	98008544		Screw
"	33001190	33002366		Panel- FRO
5	Y310376			Clip, Door Switch Harness
6	315287			Bumper Small
7	Y304578	LA-1003		Door Catch Kit
8	308017			Switch, Dryer Temperature
9	216042	22001627		Screw
10	207782			Switch, Water Temperature
11	22001188			Switch, Rotary
12	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

13	33001478	Not Available	DIAL, TIMER (ALM)
14	33001479	Not Available	CAP, END (ALM)
15	211000		SCREW, BRAKE DRUM (HEX HEAD)
16	211065		Spring, Index Wheel
17	216209	Not Available	KNOB
18	216424	Not Available	CAP, KNOB (ALM)
19	211605		Bezel, Timer Dial
20	312273		Nut, Control Knob
21	315522	33002325	Knob Assembly
22	33001480	33002336	Knob, Rotary
23	33001481	Not Available	DIAL, DRYER TIMER (ALM)
24	315317	488234	Screw 8-32 X 1/4
25	33001482	Y308025	Switch, Push To Start
26	33001477	Not Available	PANEL, CONTROL (ALM)
27	215952		Screw
28	315237		Bracket For Switch And Timer
29	33001034		Timer, Dryer
30	314482		Fastener, Spring
31	33001292	488660	Nut, Speed
32	315286		Bumper Large
33	22001180		Timer
34	22001426	Not Available	WIRE HARNESS (UPR. CANADA)
35	22001431	Not Available	WIRE HARNESS (LWR-CANADA) NA
"	22001584		Harness, Wire
36	33001368		Wire Harness, Dryer
"	22004234		Wire Harness
"	33001553		Harness, Wire

