


**Maytag LSE7804AGM 07 - FRONT PANEL & CONTROL PANEL  
(LSE7804AGM)**



Maytag [Residential Maytag LSE7804AGM Stacked Washer and Dryer Parts](#) Parts Diagram 07 - FRONT PANEL & CONTROL PANEL (LSE7804AGM)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314286</a>			Seal For Front Panel
2	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
3	33001509	<a href="#">W10169313</a>		Switch-Dor
"	Y305753	<a href="#">W10169313</a>		Switch-Dor
4	33001486	<a href="#">98008544</a>		Screw
"	33001190	<a href="#">33002366</a>		Panel- FRO
5	<a href="#">Y310376</a>			Clip, Door Switch Harness
6	<a href="#">315287</a>			Bumper Small
7	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
8	<a href="#">308017</a>			Switch, Dryer Temperature
9	216042	<a href="#">22001627</a>		Screw
10	<a href="#">207782</a>			Switch, Water Temperature
11	<a href="#">22001188</a>			Switch, Rotary
12	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping

13	33001478		Not Available	DIAL, TIMER (ALM)
14	33001479		Not Available	CAP, END (ALM)
15	211000			SCREW, BRAKE DRUM (HEX HEAD)
16	<a href="#">211065</a>			Spring, Index Wheel
17	216209		Not Available	KNOB
18	216424		Not Available	CAP, KNOB (ALM)
19	<a href="#">211605</a>			Bezel, Timer Dial
20	<a href="#">312273</a>			Nut, Control Knob
21	315522	<a href="#">33002325</a>		Knob Assembly
22	33001480	<a href="#">33002336</a>		Knob, Rotary
23	33001481		Not Available	DIAL, DRYER TIMER (ALM)
24	315317	<a href="#">488234</a>		Screw 8-32 X 1/4
25	33001482	<a href="#">Y308025</a>		Switch, Push To Start
26	33001477		Not Available	PANEL, CONTROL (ALM)
27	<a href="#">215952</a>			Screw
28	<a href="#">315237</a>			Bracket For Switch And Timer
29	<a href="#">33001390</a>			Timer
30	<a href="#">314482</a>			Fastener, Spring
31	33001292	<a href="#">488660</a>		Nut, Speed
32	<a href="#">315286</a>			Bumper Large
33	<a href="#">22001181</a>			Timer
34	22001427		Not Available	WIRE HARNESS (UPR) NA
35	<a href="#">22001585</a>			Harness, Wire
"	<a href="#">22001432</a>			Wire Harness
36	33001370		Not Available	WIRE HARNESS, MAIN (240V-50HZ)
"	<a href="#">33001555</a>			Harness, Wire

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>