


Maytag LSE9900 05 - DOOR, FRONT PANEL & CONTROL PANEL

SECTION: DOOR, FRONT PANEL & CONTROL PANEL
 MODEL: SE-S69900



Issue Date: 8/90

4

Maytag Residential Maytag LSE9900 Stacked Washer and Dryer Parts Parts Diagram 05 - DOOR, FRONT PANEL & CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	314286			Seal For Front Panel
2	212277			Screw, No.8 X 1/2 Inch
"	314474L		Not Available	FRONT PANEL-ALMOND
3	Y310376			Clip, Door Switch Harness
4	Y313927			INSTRUCTION LABEL
5	306436			Door Latch Kit-W
"	312960	489355		Screw, 8 X 1/2
6	314609		Not Available	CAUTION LABEL
7	307852		Not Available	WIRE HARNESS, MAIN (SE9900)
"	Y312953			Terminal, Edgeboard
"	910768	M0280301		Tie Electr
"	307854	WR72X242		Slide Assembly RH
8	314523			Clip
9	306070		Not Available	SPEAKER
"	212949	22001866		Screw, Relay

10	912086		Clip, Speed
11	314561	Not Available	AIR SEAL
12	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	307851	Not Available	CONTROL PANEL
13	314560	Not Available	SEAL, MOISTURE
14	Y307849	Not Available	TOUCH PAD WITH BRACKET
"	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
15	306069	33001048	Control Assembly
16	912075		Spacer, Circuit Board
17	912077		Locknut, Reader Harness
18	314482		Fastener, Spring
19	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	314481		Mounting Bracket
20	314748	488660	Nut, Speed
21	314517		Shield For Microprocessor
22	314486	Not Available	LABEL
23	Y305753	W10169313	Switch-Dor
24	314475L		Panel, Outer Door
25	Y313910		Clip, Door Liner To Outer Panel
26	Y304577	33001230	Hinge, Door
"	Y314062		Screw, Door Hinge And Panel
27	306676	Not Available	INNER DOOR WITH KNOB
28	314077		Door Seal
29	Y313911		Door Strike Retainer
30	214872		Palnut, End Cap Note: Nut, Lamp Holder
31	314476	Not Available	HANDLE,DOOR

