


Maytag LSG1000 03 - CABINET & FRONT PANEL



Maytag [Residential Maytag LSG1000 Stacked Washer and Dryer Parts](#) Parts Diagram 03 - CABINET & FRONT PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	210866			Nut, Twin Speed
2	202476			Unbalance Switch
"	213501			Screw, No.6-20 X 1-1/8 Inch
3	206421			Relay, Motor Reversing
4	215273			Clip, Spring Relay
"	212949	22001866		Screw, Relay
5	901961	W10133335		Relay, Motor
6	206423			Lower Wire Harness-AC
7	213122	27001200		Screw
"	206411L		Not Available	CABINET-ALMOND
"	207207L		Not Available	CABINET ALM---NA
"	213007			Xfor Cabinet See Cabinet, Back
8	Y059137	Y059141		Ctn. 50 Ft. 31/32 Drain Hose
"	215279	22003410		Hose, Drain
9	200461	285655		Clamp, Hose
10	214764	208847		Elbow

11	214765		Gasket, Siphon Break
12	206638		Siphon Break
"	Y014874		Screw, Idler Arm And Sleeve
13	202574	3367052	Clamp, Hose
14	215365	22001448	Hose, Pump
15	215711		Fastener, Spring
"	212982	22001650	Fastener, Spring
16	215266	Not Available	TRIM, FRONT PANEL
17	206550L		Front Panel-Almond---NA
"	910647	489355	Screw, 8 X 1/2
"	213123	22001496	Front Panel Fastener And Screw
"	207205L	22002651	Panel, Front
18	213846		Guard, Belt
"	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
19	215075		Fastener, Control Panel To Console
20	214376	22002331	Spacer, Front Panel
21	314609	Not Available	CAUTION LABEL

