


Maytag LSG7800AAW 11 - LID LOCK



22

Maytag Residential Maytag LSG7800AAW Stacked Washer and Dryer Parts Parts Diagram 11 - LID LOCK
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	810146		Not Available	SCREW
2	215378		Not Available	LID SWITCH LEVER
3	213648	98165		Screw
4	211000			SCREW, BRAKE DRUM (HEX HEAD)
5	215379		Not Available	BRACKET, LID SWITCH/LATCH
6	215270			Moisture Barrier
7	205415	279347		Switch-Lid
8	215943		Not Available	MOISTURE BARRIER
"	215381		Not Available	SCREW
9	207780			Switch, Lid Latch Assembly
10	912012	3400409		Screw
11	215268		Not Available	LID LATCH LEVER
12	215938		Not Available	SPRING FOR SOLENOID
13	207781		Not Available	SOLENOID, LID LATCH ASSY

14	215966		Heat Sink----NA
15	215245	Not Available	BRIDGE FOR TOP COVER NA
16	314664	212277	Screw, No.8 X 1/2 Inch
17	215253		Key Hole Glide
18	215246	Not Available	SPLASH SHIELD
19	214354		Screw, Top Cover To Cabnt.
20	207579	Not Available	TOP COVER (WHITE)
21	215254	Not Available	LATCH HOOK
22	215274	Not Available	TOP COVER RESTRAINT
23	910182	25-7809	Screw, No.6-20 1/2 Flthd Torx
"	211500		Washer, Bracket To Top Cover
24	215249		Palnut-Retainer
25	215247	Not Available	BUMPER FOR LID
26	215374	Not Available	GASKET FOR BLEACH CUP
"	215579	215580	Cup, Bleach
27	215551		Palnut
28	215550		Stud For Lid Handle
"	206667		Handle With Nuts
29	215251	Not Available	LID-WHITE
30	208213		Wire Harness
"	207784	Not Available	WIRE HARNESS

