


Maytag LSG7800ABW 03 - BLOWER & LINT SCREEN (LSG7800ABx)



16

Maytag Residential Maytag LSG7800ABW Stacked Washer and Dryer Parts Parts Diagram 03 - BLOWER & LINT SCREEN (LSG7800ABx)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	Y312893			Housing, Blower
2	306637			Exhaust Duct Assembly
3	410233	9703438		Ring-Retr
4	Y303836			Blower Wheel Assembly And Clamp
5	312967			Clamp, Blower Housing
6	Y312961	W10116751		Screw
7	Y313561			Screw---NA
8	Y308036		Not Available	THERMOSTAT
9	Y310632	1163839		Screw
10	306643	8544761A		Exten-Exht
11	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
12	306604			Cut-Off, Thermal Part Not Used
13	Y312901			Seal, Housing Cover
14	314846			Cover, Blower Housing

15	Y310632	1163839	Screw
16	901220		Ground Wire
17	Y313795		Guide For Lint Screen
18	Y312961	W10116751	Screw
19	314801		Outlet Duct And Grid
20	315274	488660	Nut, Speed
21	314485		Outlet Duct And Grid
22	Y312961	W10116751	Screw
23	315239		Shield For Outlet Duct
24	315238		Shield
25	310207		Screw, No.6 X 1/4 Inch
26	Y313796		Lint Seal
27	310557		Washer
"	Y312961	W10116751	Screw
28	Y306666	33001003	Screen, Lint

