


Maytag LSG7800ABW 16 - TUB-INNER & OUTER (LSG7800ABx)



30

Maytag Residential Maytag LSG7800ABW Stacked Washer and Dryer Parts Parts Diagram 16 - TUB-INNER & OUTER (LSG7800ABx)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	215733			Dispensing Cup
2	215721			Dispensing Cap
3	207538			Agitator W/Lock Screw
4	206478		Not Available	SCREW & WASHER FOR AGITATOR
5	211100			Washer, Outer Tub
6	Y054867			Washer, Lock
7	204013	6-2040130		Tub Bearin
8	200824	6-2040130		Tub Bearin
9	211130			Bearing Liner, Tub Bearing
10	204012	6-2095720		Mounting S
11	211047	6-2110472		Nut- Clamp
12	Y0A4298	6-0A57420		Seal- Agitator
13	207830		Not Available	INNER TUB W/PLUG
14	207787	12002304		Switch-WL
15	410296	596669		Clamp, Manifold

16	206405		Outer Tub
17	215258	22001616	Tube, Air
18	211641		Clamp, 1-1/16"
19	213045		Hose, Outer Tub Part Not Used
20	200900	616099	Clamp
21	205161	489503	Clamp
22	214434		Spout, Deflector
23	214495		Tube, Inlet To Tub
24	211210		Washer, Clamping Nut
25	Y015666		Washer, Retaining -
26	Y015667		Retaining Ring
27	207219		Filter, Self-Cleaning

the laundry company[®]

the laundry company[®]

the laundry company[®]