


# Maytag LSG7804AAL 08 - FRONT PANEL & CONTROL PANEL



Maytag Residential Maytag LSG7804AAL Stacked Washer and Dryer Parts Parts Diagram 08 - FRONT PANEL & CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">314286</a>			Seal For Front Panel
2	<a href="#">212277</a>			Screw, No.8 X 1/2 Inch
3	33001509	<a href="#">W10169313</a>		Switch-Dor
"	Y305753	<a href="#">W10169313</a>		Switch-Dor
4	33001486	<a href="#">98008544</a>		Screw
"	33001190	<a href="#">33002366</a>		Panel- FRO
5	<a href="#">Y310376</a>			Clip, Door Switch Harness
6	<a href="#">315287</a>			Bumper Small
7	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
8	<a href="#">308017</a>			Switch, Dryer Temperature
9	216042	<a href="#">22001627</a>		Screw
10	<a href="#">207782</a>			Switch, Water Temperature
11	<a href="#">22001188</a>			Switch, Rotary
12	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
13	22001034		Not Available	KNOB, TIMER (BLK)

14	315267	Not Available	END CAP, CONTROL PANEL (BLK)
15	211000		SCREW, BRAKE DRUM (HEX HEAD)
16	<a href="#">211065</a>		Spring, Index Wheel
17	<a href="#">215828</a>		Knob, Timer
18	216193	Not Available	CAP, TIMER KNOB (BLK)
19	<a href="#">211605</a>		Bezel, Timer Dial
20	<a href="#">312273</a>		Nut, Control Knob
21	<a href="#">315041</a>		Knob, Timer
22	<a href="#">33001291</a>		Knob, Selector Switch
23	<a href="#">33001009</a>		Dial, Dryer Timer NA
24	315317	<a href="#">488234</a>	Screw 8-32 X 1/4
25	<a href="#">Y308025</a>		Switch, Push To Start
26	33001008	Not Available	PANEL, CONTROL (BLK)
27	<a href="#">215952</a>		Screw
28	<a href="#">315237</a>		Bracket For Switch And Timer
29	<a href="#">33001034</a>		Timer, Dryer
30	<a href="#">314482</a>		Fastener, Spring
31	33001292	<a href="#">488660</a>	Nut, Speed
32	<a href="#">315286</a>		Bumper Large
33	<a href="#">22001180</a>		Timer
34	208774	Not Available	WIRE HARNESS (UPR)
"	<a href="#">22001429</a>		Wire Harness, Main
35	208776	Not Available	WIRE HARNESS (LOWER)
"	<a href="#">22001432</a>		Wire Harness
36	<a href="#">33001369</a>		Wire Harness, Dryer
"	<a href="#">33001043</a>		Wire Harness, Dryer
"	<a href="#">33001554</a>		Harness, Wire

*the laundry company*<sup>®</sup>

**lows**  
*the laundry company*<sup>®</sup>