


Maytag LSG7804ABE 08 - FRONT PANEL & CONTROL PANEL



Maytag Residential Maytag LSG7804ABE Stacked Washer and Dryer Parts Parts Diagram 08 - FRONT PANEL & CONTROL PANEL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	314286			Seal For Front Panel
2	212277			Screw, No.8 X 1/2 Inch
3	Y305753	W10169313		Switch-Dor
"	33001509	W10169313		Switch-Dor
4	33001486	98008544		Screw
"	33001191			Panel, Front
5	Y310376			Clip, Door Switch Harness
6	315287			Bumper Small
7	Y304578	LA-1003		Door Catch Kit
8	308017			Switch, Dryer Temperature
9	216042	22001627		Screw
10	207782			Switch, Water Temperature
11	22001188			Switch, Rotary
12	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
13	22001035		Not Available	DIAL, TIMER (WHT)

14	315423		End Cap, Control Panel
15	211000		SCREW, BRAKE DRUM (HEX HEAD)
16	211065		Spring, Index Wheel
17	22001198	Not Available	KNOB, TIMER (WHT)
18	216250	22001446	Cap, Knob
19	211605		Bezel, Timer Dial
20	312273		Nut, Control Knob
21	33001255		Knob, Timer
22	Y308453	22001663	Knob, Selector Switch
23	33001010		Dial, Dryer Timer
24	315317	488234	Screw 8-32 X 1/4
25	Y308449	Y308025	Switch, Push To Start
26	33001007	Not Available	PANEL, CONTROL (WHT)
27	215952		Screw
28	315237		Bracket For Switch And Timer
29	33001034		Timer, Dryer
30	314482		Fastener, Spring
31	33001292	488660	Nut, Speed
32	315286		Bumper Large
33	22001180		Timer
34	22001271		Harness, Wire
"	22001428	Not Available	WIRE HARNESS, MAIN (UPR)
35	22001272		Harness, Wire
"	22001431	Not Available	WIRE HARNESS (LWR-CANADA) NA
"	22001584		Harness, Wire
36	33001043		Wire Harness, Dryer
"	22004234		Wire Harness
"	33001369		Wire Harness, Dryer
"	33001554		Harness, Wire

