


# Maytag LSG7804ABE 11 - TOP & LID



Maytag Residential Maytag LSG7804ABE Stacked Washer and Dryer Parts Parts Diagram 11 - TOP & LID  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001272</a>			Harness, Wire
"	22001431		Not Available	WIRE HARNESS (LWR-CANADA) NA
"	22001428		Not Available	WIRE HARNESS, MAIN (UPR)
"	<a href="#">22001584</a>			Harness, Wire
"	<a href="#">22001271</a>			Harness, Wire
2	<a href="#">22001443</a>			Harness, Wire
"	<a href="#">208781</a>			Wire Harness, Lid Switch
3	<a href="#">22001194</a>			Clip, Spring
4	<a href="#">22001001</a>			Screw
5	<a href="#">208823</a>			Pc Switch, Lid
6	22001581	<a href="#">12001514</a>		Switch-Lid
"	22001444	<a href="#">12001513</a>		Switch-Lid
"	22001251	<a href="#">12001513</a>		Switch-Lid
7	22001368		Not Available	LID W/LEGEND (CANADA-WHT)

8	<a href="#">214354</a>		Screw, Top Cover To Cabnt.
9	22001064	Not Available	COVER, TOP (WHT)
10	<a href="#">212716</a>		Bumper, Lid
11	22001202	<a href="#">22001006</a>	Cup, Bleach
12	215374	Not Available	GASKET FOR BLEACH CUP
13	<a href="#">22001189</a>		Rod, Restraint
14	<a href="#">22001208</a>		Rod, Counter Balance
15	<a href="#">Y216184</a>		Spring, Counter Balance
16	<a href="#">22001193</a>		Bearing, Counter Balance
17	<a href="#">207166</a>		Switch, Check
18	<a href="#">22001283</a>		Trigger
19	<a href="#">22001183</a>		Screw
"	<a href="#">215537</a>		Screw
20	<a href="#">22001285</a>		Holder, Switch
21	<a href="#">22001286</a>		Switch, Arm
22	<a href="#">22001287</a>		Spring, Switch
23	<a href="#">22001250</a>		Glide, Switch Arm

