


# Maytag LSG7806ABE 12 - TOP & LID



Maytag Residential Maytag LSG7806ABE Stacked Washer and Dryer Parts Parts Diagram 12 - TOP & LID  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22001584</a>			Harness, Wire
"	<a href="#">22001941</a>			Harness, Washer
2	<a href="#">22001939</a>			Harness, Lid Switch
3	<a href="#">22001194</a>			Clip, Spring
4	<a href="#">22001001</a>			Screw
5	<a href="#">208823</a>			Pc Switch, Lid
6	22001581	<a href="#">12001514</a>		Switch-Lid
7	22001368		Not Available	LID W/LEGEND (CANADA-WHT)
8	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
9	22001064		Not Available	COVER, TOP (WHT)
10	<a href="#">212716</a>			Bumper, Lid
11	<a href="#">22001006</a>			Cup, Bleach
12	215374		Not Available	GASKET FOR BLEACH CUP
13	<a href="#">22001189</a>			Rod, Restraint
14	<a href="#">22001208</a>			Rod, Counter Balance
15	<a href="#">Y216184</a>			Spring, Counter Balance

16	<a href="#">22001193</a>	Bearing, Counter Balance
17	<a href="#">207166</a>	Switch, Check
18	<a href="#">22001283</a>	Trigger
19	<a href="#">22001183</a>	Screw
"	<a href="#">215537</a>	Screw
20	<a href="#">22001285</a>	Holder, Switch
21	<a href="#">22001286</a>	Switch, Arm
22	<a href="#">22001287</a>	Spring, Switch
23	<a href="#">22001250</a>	Glide, Switch Arm

