


Maytag LSG7806ABQ 03 - CABINET-DRYER (LSG7806ABQ)



Maytag Residential Maytag LSG7806ABQ Stacked Washer and Dryer Parts Diagram 03 - CABINET-DRYER (LSG7806ABQ)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	303846	22003781		Screw, Ground Strap
2	314663	214354		Screw, Top Cover To Cabnt.
3	Y313561			Screw----NA
4	314470		Not Available	COVER, TERMINAL
5	22002669		Not Available	CABINET, ASSEMBLY (BSQ)
6	312548			Fastener-Access Panel To CA
7	Y308205	33001623		Buzzer, Non-Adjustable
8	33001309			Block, Terminal
9	211168	W10139210		Screw, 8-18 X 5/16
10	33001212			Board, Control-Moisture Sensor
11	306128		Not Available	BRACE FOR STAND-ACCESSORY
12	22001929	8534021		Clamp, Recirc Hose Retainer
13	22002595			Bumper
14	Y310632	1163839		Screw

15	314489		Guide, Pin
16	214872		Palnut, End Cap Note: Nut, Lamp Holder
17	Y313262	W10116752	Retainer-
18	315471	22003298	Retainer, Wire
19	22001941		Harness, Washer
"	33001554		Harness, Wire
20	314477		Screw, Access Panel
21	22002671	33002365	Panel- Acc
"	33001130		Shield, Reflective
22	314482		Fastener, Spring
23	314498		Pad, Dryer Leg
25	Y052740	62739	Nut, Lock
26	Y314137		Foot, Rubber
27	Y305086		Adjustable Leg And Nut
28	210684		Foot, Adjustable Leg
29	Y302699	22003428	Leg, Adjustable
30	Y052721		Nut, Terminal Block Plate
31	210385		Lock Nut For Adjustable Leg
32	314499	Not Available	BRACE
33	214354		Screw, Top Cover To Cabnt.
36	215954		Screw
37	33001308	Not Available	CORD, POWER

