


# Maytag MAF18MC4AL 04 - CONTROL MODULE (MAF18MC4Ax)



Maytag Residential Maytag MAF18MC4AL Washer Parts Parts Diagram 04 - CONTROL MODULE (MAF18MC4Ax)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001104		Not Available	CONTACTOR, AUX. ADDER
"	<a href="#">24001737</a>			Relay
"	<a href="#">24001738</a>			Relay
002	24001744		Not Available	BOOT, PUSH BUTTON
003	<a href="#">24001254</a>			Switch, Momentary
004	24001419	<a href="#">W10139757</a>		Nut
005	24001223		Not Available	SWITCH, DUAL LEVEL
006	24001412		Not Available	STRIP, TERMINAL
007	24001414	<a href="#">4450038</a>		Screw
008	24001030		Not Available	DECAL,INSUL.TERM STIRP (33-40)
009	W10124350		Not Available	PART NUMBER NOT AVAILABLE
010	W10124350		Not Available	PART NUMBER NOT AVAILABLE
011	<a href="#">24001357</a>			Screw, Stainless Steel
012	<a href="#">24001358</a>			Washer, Flat

013	NLA		Not Available	SWITCH, CYCLE SELECTOR
014	NLA		Not Available	NUT, FIBERLOCK
015	24001417	<a href="#">7103P070-60</a>		Nut, Top Pilot
016	<a href="#">24001415</a>			Washer, S.s.
017	NLA		Not Available	DECAL,INSUL. TERM STRIP (1-8)
018	NLA		Not Available	DECAL,INSUL. TERM STRIP (9-16)
019	NLA		Not Available	DECAL,INSUL. TERM STRIP (17-24)
020	NLA		Not Available	DECAL,INSUL. TERM STRIP (25-32)
021	24001411	<a href="#">313806</a>		Screw
022	<a href="#">24001178</a>			Kit, Timer Cycle
023	<a href="#">24001577</a>			Motor, Timer
024	W10124350		Not Available	PART NUMBER NOT AVAILABLE
025	24001578	<a href="#">3196170</a>		Screw
026	<a href="#">24001247</a>			Capacitor, Door Lock
027	24001248		Not Available	PC BOARD, DOOR UNLOCK (110V)
"	<a href="#">24001742</a>			Board, P.C.
028	<a href="#">24001580</a>			Screw, S.s.
029	<a href="#">24001579</a>			Washer, S.s.
030	<a href="#">24001176</a>			Kit, Timer Delay
031	<a href="#">24001295</a>			Lockwasher, S.s.

