


Maytag MAF18MC4VS 03 - DOOR SAFETY INTERLOCK (MAF18MC4Vx)



Maytag Residential Maytag MAF18MC4VS Washer Parts Diagram 03 - DOOR SAFETY INTERLOCK (MAF18MC4Vx)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	24001642			Screw, S.s.
002	24001483		Not Available	CATCH, DOOR LOCK
003	24001323			Screw
004	24001484		Not Available	COVER, DOOR LOCK PLATE
005	24001295			Lockwasher, S.s.
006	24001342	74005230		Nut, Lock
007	24001485			Washer, Shoulder
008	24001101			Solenoid, Door Rel
009	24001358			Washer, Flat
010	24001250			Button, Push
011	24001481	Y707702		Locknut
012	24001480			Washer, Teflon
013	24001487		Not Available	COVER, DOOR LOCK ASSY.
014	24001476			Nut, Fiberlock
015	24001229			Switch, Door Lock
016	24001477		Not Available	SPACER, NYLON (No.6)

017	24001643		Screw, S.s.
018	24001479		Screw, S.s.
019	24001301	67006964	Screw, Glide
020	NLA	Not Available	PLATE, DOOR LOCK
021	24001102		Solenoid, Door Lck
022	24001305		Nut, Fiberlock
023	24001255		Switch, Door Handle
024	24001736	24001425	Nut, Fiberlock, Pltd
025	24001230		Lever, Door Lock
026	24001293		Spring, Torsion
027	24001559		Shim, Door Lock
028	24001488	Not Available	SHIELD, SPLASH (DOOR LOCK)
"	24001640		Door Lock Complete

