


# Maytag MAF25MC4TS 06 - DOOR LOCK (MAF25MC4Tx)



Maytag Residential Maytag MAF25MC4TS Washer Parts Parts Diagram 06 - DOOR LOCK (MAF25MC4Tx)  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By              | Status        | Part Description       |
|------|--------------------------|--------------------------|---------------|------------------------|
| 001  | <a href="#">24001640</a> |                          |               | Door Lock Complete     |
| "    | <a href="#">24001642</a> |                          |               | Screw, S.s.            |
| 002  | 24001483                 |                          | Not Available | CATCH, DOOR LOCK       |
| 003  | <a href="#">24001323</a> |                          |               | Screw                  |
| 004  | 24001484                 |                          | Not Available | COVER, DOOR LOCK PLATE |
| 005  | <a href="#">24001295</a> |                          |               | Lockwasher, S.s.       |
| 006  | 24001342                 | <a href="#">74005230</a> |               | Nut, Lock              |
| 007  | <a href="#">24001485</a> |                          |               | Washer, Shoulder       |
| 008  | <a href="#">24001101</a> |                          |               | Solenoid, Door Rel     |
| 009  | <a href="#">24001358</a> |                          |               | Washer, Flat           |
| 010  | <a href="#">24001250</a> |                          |               | Button, Push           |
| 011  | 24001481                 | <a href="#">Y707702</a>  |               | Locknut                |
| 012  | <a href="#">24001480</a> |                          |               | Washer, Teflon         |
| 013  | 24001487                 |                          | Not Available | COVER, DOOR LOCK ASSY. |
| 014  | <a href="#">24001476</a> |                          |               | Nut, Fiberlock         |
| 015  | <a href="#">24001229</a> |                          |               | Switch, Door Lock      |

|     |                          |                          |               |                            |
|-----|--------------------------|--------------------------|---------------|----------------------------|
| 016 | 24001477                 |                          | Not Available | SPACER, NYLON (No.6)       |
| 017 | <a href="#">24001479</a> |                          |               | Screw, S.s.                |
| 018 | <a href="#">24001643</a> |                          |               | Screw, S.s.                |
| 019 | 24001301                 | <a href="#">67006964</a> |               | Screw, Glide               |
| 020 | NLA                      |                          | Not Available | PLATE, DOOR LOCK           |
| 021 | <a href="#">24001102</a> |                          |               | Solenoid, Door Lck         |
| 022 | <a href="#">24001305</a> |                          |               | Nut, Fiberlock             |
| 023 | <a href="#">24001255</a> |                          |               | Switch, Door Handle        |
| "   | 24001257                 | <a href="#">24001255</a> |               | Switch, Door Handle        |
| 024 | <a href="#">24001425</a> |                          |               | Nut, Fiberlock, Pltd       |
| 025 | <a href="#">24001230</a> |                          |               | Lever, Door Lock           |
| 026 | <a href="#">24001293</a> |                          |               | Spring, Torsion            |
| 027 | <a href="#">24001559</a> |                          |               | Shim, Door Lock            |
| 028 | 24001488                 |                          | Not Available | SHIELD, SPLASH (DOOR LOCK) |

